

8254-Style Frequency Calculation:


$$\text{Output Frequency} = \frac{\text{Clock Frequency}}{\text{Counts}}$$

$$\text{Maximum Output Frequency} = \frac{\text{Clock Frequency}}{\text{Minimum Count}}$$


↑
Count RANGE
↓

$$\text{Minimum Output Frequency} = \frac{\text{Clock Frequency}}{\text{Maximum Count}}$$


Output Frequencies, 10 Mhz and 1 Mhz Cl




Output Frequencies, 10 Mhz and 1 Mhz CI




Output frequencies, 10 Mhz and 1 Mhz Clk







Output frequencies, 1 Mhz Clock



Output frequencies, 10 Mhz Clock



Output Frequencies, 10 Mhz and 1 Mhz Cl





DACPORT Low Cost, Complete μP-Compatible 8-Bit DAC

AD558*




Figure 1a. AD558 Pin Configuration (DIP)




Table I. AD558 Control Logic Truth Table

Input Data	\overline{CE}	\overline{CS}	DAC Data	Latch Condition
0	0	0	0	“Transparent”
1	0	0	1	“Transparent”
0	g	0	0	Latching
1	g	0	1	Latching
0	0	g	0	Latching
1	0	g	1	Latching
X	1	X	Previous Data	Latched
X	X	1	Previous Data	Latched




Table Entry Number:

	0	1	2	3	4	5	6	7
Analog Sinewave:	0	0.707	1	0.707	0	-0.707	-1	-0.707
Offset Analog:	1	1.707	2	1.707	1	0.293	0	0.293
Times 255/2, converted to hex...	7Fh	DAh	FFh	DAh	7Fh	25h	00h	25h

- Eight (8) entries in the sinewave data table
- Limit timer interrupts to an advance every 1/8th second
- Determine the counts/advance of the table counter:
- First, try a 3-bit table counter to make a 1 Hz sinewave:

$$2^3 \frac{\text{counts}}{\text{period}} \bullet 1 \frac{\text{period}}{\text{second}} \bullet \frac{1}{8} \frac{\text{seconds}}{\text{advance}} = 1 \frac{\text{count}}{\text{advance}}$$

- Eight (8) entries in the sinewave data table
- Limit timer interrupts to an advance every 1/8th second
- Determine the counts/advance of the table counter:
- First, try a 3-bit table counter to make a 1 Hz sinewave:

$$2^3 \frac{\text{counts}}{\text{period}} \bullet 1 \frac{\text{period}}{\text{second}} \bullet \frac{1}{8} \frac{\text{seconds}}{\text{advance}} = 1 \frac{\text{count}}{\text{advance}}$$

- Now, try a 3-bit table counter to make a **1.5 Hz** sinewave:

$$2^3 \frac{\text{counts}}{\text{period}} \bullet 1.5 \frac{\text{period}}{\text{second}} \bullet \frac{1}{8} \frac{\text{seconds}}{\text{advance}} = 1 \frac{\text{count}}{\text{advance}}$$

(with integer rounding)

- Eight (8) entries in the sinewave data table
- Limit timer interrupts to an advance every 1/8th second
- Determine the counts/advance of the table counter:
- First, try a 3-bit table counter to make a 1 Hz sinewave:

$$2^3 \frac{\text{counts}}{\text{period}} \bullet 1 \frac{\text{period}}{\text{second}} \bullet \frac{1}{8} \frac{\text{seconds}}{\text{advance}} = 1 \frac{\text{count}}{\text{advance}}$$

- Now, try a 3-bit table counter to make a **1.5 Hz** sinewave:

$$2^3 \frac{\text{counts}}{\text{period}} \bullet 1.5 \frac{\text{period}}{\text{second}} \bullet \frac{1}{8} \frac{\text{seconds}}{\text{advance}} = 1 \frac{\text{count}}{\text{advance}}$$

(with integer rounding)

- Now, try a **4-bit** table counter to make a **1.5 Hz** sinewave:

$$2^4 \frac{\text{counts}}{\text{period}} \bullet 1.5 \frac{\text{period}}{\text{second}} \bullet \frac{1}{8} \frac{\text{seconds}}{\text{advance}} = 3 \frac{\text{count}}{\text{advance}}$$